



	<p>KIT FIXING-BAR 3 x 3 pcs. 8" brackets</p> <p>KIT **98655-384</p>		<p>KIT GIOTTILINE - FENDT 3 x 3 pcs. 6" brackets</p> <p>KIT **98655-725</p>
<p style="text-align: center;"> WITHOUT DRILLING </p> <p>After 1994 Before 06/2006</p>	<p>KIT DUCATO-JUMPER-BOXER Before 6/2006 2 x LOW PROFILE 2 pcs. 8" brackets</p> <p>KIT **98655-693</p>		<p>KIT KNAUS YAT 3 x 3 pcs. 6" brackets</p> <p>KIT **98655-723</p>
<p style="text-align: center;"> WITHOUT DRILLING </p> <p>After 1994 Before 06/2006</p>	<p>KIT DUCATO-JUMPER-BOXER 2 x HIGH PROFILE 2 pcs. 8" brackets</p> <p>KIT **98655-373</p>	<p style="text-align: right;">Only for H2 Model</p>	<p>KIT IVECO DAILY H2 3 x 2 pcs. 6" brackets 1 pc. 8" brackets</p> <p>KIT **98655-733</p>
<p style="text-align: center;">Only for H3 Model</p>	<p>KIT IVECO DAILY H3 3 x 3 pcs. 6" brackets</p> <p>KIT **98655-704</p>	<p style="text-align: right;"></p>	<p>KIT RENAULT MASTER 3 x 2 pcs. 11 1/2" brackets 1 pc. 8" bracket</p> <p>KIT **98655-468</p>
	<p>KIT LAIKA KREOS 05 3 x 3 pcs. 6" brackets</p> <p>KIT **98655-698</p>	<p style="text-align: right;"></p>	<p>KIT CARTHAGO CHIC 1 x</p> <p>**13' - 98655-736 **15' - 98655-737 **16' - 98655-738</p>
	<p>LAIKA KREOS 1 x</p> <p>**12' - 98655-358 **13' - 98655-731 * 15' 9" - 98655-400</p>	<p style="text-align: right;"></p>	<p>KIT MERCEDES SPRINTER Standard highroof 3 x 2 pcs. 19 3/4" brackets 1 pcs. 10" bracket</p> <p>KIT *98655-746</p>
		<p style="text-align: right;"></p>	<p>KIT DUCATO-JUMPER-BOXER After 6/2006 2 x 2 pcs. 8" brackets with rubber joints</p> <p>KIT **98655-745</p>

* Stock item ** Special order